


EXFO EX1

Ethernet Services Broadband Tester



Copyright © 2017–2020 EXFO Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, be it electronically, mechanically, or by any other means such as photocopying, recording or otherwise, without the prior written permission of EXFO Inc. (EXFO).

Information provided by EXFO is believed to be accurate and reliable. However, no responsibility is assumed by EXFO for its use nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent rights of EXFO.

EXFO's Commerce And Government Entities (CAGE) code under the North Atlantic Treaty Organization (NATO) is 0L8C3.

The information contained in this publication is subject to change without notice.

Trademarks

EXFO's trademarks have been identified as such. However, the presence or absence of such identification does not affect the legal status of any trademark.

Units of Measurement

Units of measurement in this publication conform to SI standards and practices.

April 27, 2020

Document version: 7.0.0.1

Contents

Regulatory Information	v
1 Introducing the EXFO EX1	1
EXFO EX1 Device	2
Technical Specifications	7
Conventions	8
2 Safety Information	9
Additional Laser Safety Information	11
Electrical Safety Information	12
Other Safety Symbols	12
3 Getting Started	13
Turning the EXFO EX1 Device On	13
Connecting the RJ45 and SFP Ports	13
Installing the Smart Device Application	15
Starting the Speedtest for the First Time	16
4 EXFO EX1 Main Menu	17
Device Information	17
Connection	18
Speedtest	20
Reports	21
About	23
5 Speedtest	25
Start/Stop	26
Client/Server Information	27
Expandable Status Bar	27
Subtests	29
Quick Report	30
Settings	30
6 Speedtest Settings	31
Test	31
Reports	38
System	39

7	Maintenance	45
	Recalibrating the Unit	45
	Recharging the Battery	46
	Replacing the Battery	47
	Cleaning LC Connectors	49
	Recycling and Disposal	49
8	Troubleshooting	51
	Solving Common Problems	51
	Contacting the Technical Support Group	52
	Transportation	52
9	Warranty	53
	General Information	53
	Liability	54
	Exclusions	54
	Certification	54
	Service and Repairs	55
	EXFO Service Centers Worldwide	56
A	Specifications	57
	General Specifications	57
B	Glossary	59
	Acronym List	59
	Ethernet Interface and Signal	63
	Index	65

Regulatory Information

Canada and USA Electromagnetic Interference Regulatory Statement

Electronic test and measurement equipment is exempt from FCC part 15, subpart B compliance in the United States of America and from ICES-003 compliance in Canada. However, EXFO Inc. makes reasonable efforts to ensure compliance to the applicable standards.

The limits set by these standards are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the user documentation, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

European Electromagnetic Compatibility Regulatory Statement

Warning: This is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures. Your product is certified for (or is suitable for) use in industrial electromagnetic environments.

General Wireless Compliance Related Information

Your unit comes with an internal wireless module (adapter) and antenna for which the information hereafter applies:

Regulatory Information

This product does not contain any wireless user-serviceable components. Any unauthorized product changes or modifications will invalidate warranty and all applicable regulatory certifications and approvals.

Canada and USA Wireless Compliance Related Information

Your unit comes with an internal wireless module (adapter) and antenna for which the information hereafter applies:

- This device complies with Part 15 of the FCC Rules.
- This device complies with Innovation, Sciences and Economic Development Canada license-exempt RSS standards.
- Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference
 - and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.

Use in Specific Environments:

- The use of wireless products in hazardous locations is limited by the constraints posed by the safety directors of such environments.
- The use of wireless products on airplanes is governed by the Federal Aviation Administration (FAA).
- The use of wireless products in hospitals is restricted to the limits set forth by each hospital.
- Do not operate a portable transmitter near unshielded blasting caps or in an explosive environment.
- This wireless product is restricted to indoor use due to its operation in the 5.15 to 5.25 GHz and 5.470 to 5.75 GHz frequency ranges.

- Innovation, Sciences and Economic Development Canada requires this product to be used indoors for the frequency range of 5.15 GHz to 5.25 GHz to reduce the potential for harmful interference to co-channel mobile satellite systems.
- High-power radars are allocated as the primary users of the 5.25 to 5.35 GHz, and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage to this device.

Radiation Exposure Statement:

- The product complies with the US/Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this user documentation.
- Further RF exposure reduction can be achieved if the device can be kept as far as possible from the user's body. For compliance to RF exposure requirements, a minimum separation distance of 20 centimeters (8 inches) must be maintained between the EXFO EX1 device and the user or bystanders.

European Wireless Compliance Related Information

The information about the Bluetooth® and Wi-Fi frequency bands is as follows:

- Bluetooth®: Between the frequencies 2400.0 MHz - 2483.5 MHz.
The output power is 12 dBm typical.
- Wi-Fi: Between the frequencies 2400.0 MHz - 2483.5 MHz.
The maximum output power is 18 dBm.
- Wi-Fi: Between the frequencies 5150.0 MHz - 5825.0 MHz.
The maximum output power is 19 dBm.

This is a 2.4 GHz and 5 GHz wideband transmission system (transceiver), intended for use in all EU member states and EFTA countries, except in France and Italy where restrictive use applies.

In Italy, the end-user should apply for a license at the national spectrum authorities in order to obtain authorization to use the device for setting up outdoor radio links and/or for supplying access to telecommunications and/or network services.

This device may not be used for setting up radio links in France, and in some areas the RF output power may be limited to 10 mW EIRP in the frequency range of 2454 - 2483.5 MHz. For detailed information, the end-user should contact the national spectrum authority in France. In the European Union, the low band 5.15 - 5.35 GHz is for indoor use only.

Local Restrictions on 802.11a, 802.11b, 802.11d, 802.11g, 802.11n, and 802.11ac Radio Usage

Due to the fact that the frequencies used by 802.11a, 802.11b, 802.11d, 802.11g, 802.11n, and 802.11ac wireless LAN devices may not yet be harmonized in all countries, 802.11a, 802.11b, 802.11d, 802.11g, 802.11n, and 802.11ac products are designed for use only in specific countries, and are not allowed to be operated in countries other than those of designated use. As a user of these products, you are responsible for ensuring that the products are used only in the countries for which they were intended and for verifying that they are configured with the correct selection of frequency and channel for the country of use.

The device transmit power control (TPC) interface is part of the Intel[®] PROSet/Wireless WiFi Connection Utility Software. Operational restrictions for Equivalent Isotropic Radiated Power (EIRP) are provided by the system manufacturer. Any deviation from the permissible power and frequency settings for the country of use is an infringement of national law and may be punished as such.

European Declaration of Conformity

Hereby, EXFO declares that the radio equipment type “Wideband Data Transmission” is in compliance with European Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following Internet address: www.exfo.com/en/resources/legal-documentation.

Laser



Your instrument is a Class 1 laser product in compliance with standards IEC 60825-1: 2007/2014 and 21 CFR 1040.10, except for deviations pursuant to Laser Notice No. 42, dated December 18, 1989.

1 **Introducing the EXFO EX1**

Designed to be paired with a smart device, the EXFO EX1 is a one-of-a-kind Ethernet tester used to qualify broadband connections delivered to both residential and business Ethernet customers—enabling service providers to validate delivery of full line rate Gigabit Ethernet speeds to their subscribers. The EXFO EX1’s advantage is two-fold: it includes FPGA-powered hardware, as well as the industry-leading Speedtest powered by Ookla¹ algorithm, which together give service providers repeatable and reliable metrics, every time.

The EXFO EX1 ultra-intuitive application runs directly on a field technician’s smart device to visualize all tasks performed including connection, setup, results-gathering, report generation, and cloud-enabled firmware upgrades.

1. Ookla is a third party provider. The Ookla Speedtest Powered technology involves Ookla owned and/or controlled servers that may or may not be within your network. Ookla retains the right to aggregate test results and to monetize aggregated results as they see fit.

Introducing the EXFO EX1

EXFO EX1 Device

EXFO EX1 Device



USB-C Charging Port

The battery of the EXFO EX1 device is not fully charged at the factory. Charge the battery before using the EXFO EX1 device for the first time or when it has been unused for extended periods.

The battery needs to be fully charged before using the unit for the first time.

To charge the EXFO EX1 device:

- 1.** Connect the supplied USB cable to the USB power adapter.
- 2.** Connect the other end of the USB cable to the EXFO EX1 USB-C charging port.
- 3.** Connect the USB power adapter to a power outlet.

The battery is fully charged when the battery green LED stops flashing. The charge cycle starts and stops automatically.

Note: *Refer to Recharging the Battery on page 46 for more information.*

Introducing the EXFO EX1

EXFO EX1 Device

On/Off Switch and LED

Turns the EXFO EX1 device on or off.

- To turn the EXFO EX1 device on, press and hold the on/off switch (about 1 second) until the LED starts flashing.



IMPORTANT

The EXFO EX1 device automatically shuts down after 3 minutes (by default) of inactivity when the EXFO EX1 device is not charging using the provided USB power adapter. Refer to **Power Saving** on page 43 for more information.

- To turn the EXFO EX1 device off, press and hold the on/off switch (about 5 seconds) until the LED starts flashing, then the LED turns off.

The power LED reports the EXFO EX1 device status as follows:

LED State	Description
Off	EXFO EX1 device is turned off.
Green	EXFO EX1 device is turned on and ready to be used.
Green flashing fast	EXFO EX1 device is booting or shutting down.
Amber flashing	EXFO EX1 device is performing a firmware update.
Red	EXFO EX1 device failed to boot.

Battery LED

The battery LED of the EXFO EX1 device indicates the battery state as follows:

LED Color/State	Description
Red	Battery very low (less than 5%), not charging.
Red flashing	Battery very low (less than 5%), charging.
Amber	Battery low (between 5 and 25%), not charging.
Amber flashing	Battery low (between 5 and 25%), charging.
Green	Battery charging is completed, plugged-in.
Green flashing	Battery charging (more than 25%).
Off	Either the EXFO EX1 device is turned off or the battery is above 25% and not charging.

Reset Pin Hole

The reset pin hole button restores the EXFO EX1 device to its factory settings.



IMPORTANT

The reset pin hole should only be used as a last solution when encountering a serious problem with the EX1 device.

Resetting the EXFO EX1 device to its default configuration performs the following:

- Returns to factory firmware version.
- Returns to factory default settings.
- Clears all test reports from the EXFO EX1 device memory.

To return the EXFO EX1 device to its default factory settings:

1. Turn the EXFO EX1 device off.
2. Press and hold the pin hole button.
3. Press and hold the on/off switch (about 2 seconds).
4. Release the on/off switch.
5. Release the pin hole button.

After around 10 seconds, the power LED starts flashing (amber) indicating the reset is in progress. Once the reset is completed, the EXFO EX1 device will reboot.

RJ45 Port and LEDs

The RJ45 port is mainly used for testing the Ethernet network using an electrical wired connection: 10Base-T, 100Base-TX, and 1000Base-T. It can also be used to connect to the network for firmware upgrade (refer to **Software on page 43**).

LEDs:

- The LINK green LED is on when the link is up, off when the link is down, and flashing when frames are transmitted and/or received.
- The DUPLEX green LED is on for Full Duplex mode, off for Half Duplex mode, and flashing when collisions are detected.

SFP Port and LEDs

The SFP port is used for 1 GE and GPON 1.2G Upstream/2.4G Downstream optical interfaces.

LASER red LED is on when the EXFO EX1 device is emitting an optical laser signal.

LINK green LED is on when the link is up, off when the link is down, and flashing when frames are transmitted and/or received.

Technical Specifications

To obtain this product's technical specifications, visit the EXFO Web site at *www.exfo.com*.

Conventions

Before using the product described in this guide, you should understand the following conventions:



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in *death or serious injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *minor or moderate injury*. Do not proceed unless you understand and meet the required conditions.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in *component damage*. Do not proceed unless you understand and meet the required conditions.



IMPORTANT

Refers to information about this product you should not overlook.

2 **Safety Information**



WARNING

Do not install or terminate fibers while a light source is active. Never look directly into a live fiber and ensure that your eyes are protected at all times.



WARNING

The use of controls, adjustments and procedures, namely for operation and maintenance, other than those specified herein may result in hazardous radiation exposure or impair the protection provided by this unit.



WARNING

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



WARNING

Use only accessories designed for your unit and approved by EXFO. For a complete list of accessories available for your unit, refer to its technical specifications or contact EXFO.



IMPORTANT

Refer to the documentation provided by the manufacturers of any accessories used with your EXFO product. It may contain environmental and/or operating conditions limiting their use.



IMPORTANT

When you see the following symbol on your unit , make sure that you refer to the instructions provided in your user documentation. Ensure that you understand and meet the required conditions before using your product.



IMPORTANT

When you see the following symbol on your unit , it indicates that the unit is equipped with a laser source, or that it can be used with instruments equipped with a laser source. These instruments include, but are not limited to, modules and external optical units.



IMPORTANT

Other safety instructions relevant for your product are located throughout this documentation, depending on the action to perform. Make sure to read them carefully when they apply to your situation.



WARNING

Use in specific environments: (1) The use of wireless adapters in hazardous locations is limited by the constraints posed by the safety directors of such environments. (2) The use of wireless adapters in hospitals is restricted to the limits set forth by each hospital.

Do not operate a portable transmitter (including this wireless adapter) near unshielded blasting caps or in an explosive environment.




CAUTION

When you use the unit outdoors, ensure that it is protected from liquids, dust, direct sunlight, precipitation, and full wind pressure.

Use the external power supply indoors only.

Additional Laser Safety Information

This product employs Class 1 Laser transceivers.



WARNING

When the LASER LED is on, the module is transmitting an optical signal on the SFP transceiver port.

Safety Information

Electrical Safety Information

Electrical Safety Information

Note: To ensure that the unit is completely turned off, disconnect the power cable and remove the battery.



WARNING

- Use the external power supply indoors only.
- Position the unit so that the air can circulate freely around it.
- Operation of any electrical instrument around flammable gases or fumes constitutes a major safety hazard.
- To avoid electrical shock, do not operate the unit if any part of the outer surface (covers, panels, etc.) is damaged.
- Only authorized personnel should carry out adjustments, maintenance or repair of opened units under voltage. A person qualified in first aid must also be present. Do not replace any components while the power cable and battery are connected.
- Capacitors inside the unit may be charged even if the unit has been disconnected from its electrical supply.
- Use only the listed and certified USB power adapter provided by EXFO with your unit. It provides reinforced insulation between primary and secondary, and is suitably rated for the country where the unit is sold.

Other Safety Symbols

One or more of the following symbols may also appear on the EXFO EX1 device or its USB power adapter.

Symbol	Meaning
	Direct current
	Alternating current

3 Getting Started

This section describes the EXFO EX1 device setup, smart device software installation, then a quick procedure to initiate a test.

Turning the EXFO EX1 Device On

Note: Make sure the EXFO EX1 device is fully charged, refer to *Recharging the Battery* on page 46.

Turn the EXFO EX1 device on by pressing the on/off switch for 1 second (refer to *On/Off Switch and LED* on page 4).

Connecting the RJ45 and SFP Ports

Note: For wireless test (Wi-Fi) there is no need to connect these ports. However a network connection using the RJ45 port may be required for firmware upgrade (refer to **Software** on page 43).



RJ45 Port

The RJ45 port is used for testing the Ethernet network using a wired electrical connection. It can also be used to connect to the network for firmware upgrade (refer to **Software** on page 43).

Connect the RJ45 port of the EXFO EX1 device to the Ethernet network and make sure the link is up (refer to *RJ45 Port and LEDs* on page 7).

Getting Started

Connecting the RJ45 and SFP Ports

SFP Port

The SFP port is used for testing an Ethernet/GPON optical network. Insert an SFP/GPON optical transceiver module into the EXFO EX1 interface receptacle.

Carefully connect optical fibre cable(s) to the transceiver IN/OUT port(s). To ensure good signal quality, make sure that the optical fibre connector is fully inserted into the optical connector port.



CAUTION

To prevent exceeding the maximum input power level please use an attenuator when a loopback configuration is used.



CAUTION

Before inserting an optical module into the interface receptacle, inspect the receptacle to make sure nothing is inside.



WARNING

Use only EXFO supported transceivers. Refer to www.exfo.com for the list of supported transceivers. Using non-supported transceivers can affect the performance and accuracy of the test; in the case of GPON the test may won't work.

Note: *Do not replace the transceiver while the test is running to avoid distorting results. First stop the test, replace the transceiver, and then restart the test.*

Installing the Smart Device Application

The EXFO EX1 application needs to be installed on the smart device that will be used to control the EXFO EX1 device.

Smart Device Minimum Requirements

- Operation System:
 - Android 6.0 or above.
 - OR
 - Apple iOS 10 or above.
- Bluetooth Low Energy (BLE): version 4.0 or above; minimum recommended is version 4.2.

Software Installation

To install the EXFO EX1 application on a smart device:

- 1.** From an Android smart device, open **Play Store** (Google).
- OR
- 2.** From an Apple smart device, open **App Store**.
- 3.** Search for EXFO or EXFO EX1 to locate the EXFO EX1 application.
- 4.** Install the EXFO EX1 application.

Starting the Speedtest for the First Time


It is possible to start the Speedtest from the smart device EXFO EX1 application assuming the EXFO EX1 device is turned on and connected to the network to be tested.

To start the Speedtest:

- 1.** Start the EXFO EX1 application on the smart device. 
Ensure that Bluetooth is enabled on the smart device.
 - 1a.** For Android smart devices, confirm that the EXFO EX1 application can access the smart device location otherwise the application will not work.
 - 1b.** Confirm the enabling of **Report Diagnostic Data**. Refer to *Diagnostics* on page 42 for more information.
- 2.** From the **Connection** page, select an EXFO EX1 device from the list (refer to *Connection* on page 18).
- 3.** Once connected, the application opens automatically the **Speedtest** page (refer to *Speedtest* on page 25).
 - 3a.** Tap the setting icon  and set the test parameters (see *Speedtest Settings* on page 31).
 - 3b.** Make sure the status bar is displaying the interface rate (refer to *Speedtest* on page 25).
- 4.** From the **Speedtest** page, tap the start button  (refer to *Start/Stop* on page 26).
- 5.** Once the test is completed, tap the quick report button  to consult the full test results (refer to *Speedtest* on page 25).

4 EXFO EX1 Main Menu

Tab the main menu button: 



Note: Only **Connection** and **About** are available when not connected to an EXFO EX1 device.

Device Information

The following device information is only available when connected to an EXFO EX1 device.

- **Device Name:** Indicates the name of the connected EXFO EX1 device which is editable, refer to *Device Information* on page 43.
- **Device Date and Time:** Indicates the current date and time of the EXFO EX1 device.
- **Device Battery:** Indicates the battery status and the percentage of the remaining battery charge level of the EXFO EX1 device. Tapping on the battery icon, opens the battery information and settings, refer to *Battery* on page 42 for more information.

Connection

Accessing this page automatically scans and lists all discovered EXFO EX1 devices using Bluetooth Low Energy (BLE).

Note: *The **Connection** page is displayed by default when the application is started for the first time or when the application cannot re-connect to the previously connected EXFO EX1 device.*

Available Devices

Discovered EXFO EX1 devices appear with their device name and serial number, an update message may appear, and an icon to its left as follows:

Icon	Description
	Indicates that the firmware of the EXFO EX1 device is compatible with the EXFO EX1smart device application.
	Indicates that either: <ul style="list-style-type: none">▶ EX1 update required: The EXFO EX1 device firmware is not compatible with the smart device application and must be updated.▶ App update required: The smart device application is not compatible with the EXFO EX1 device firmware and must be updated.▶ OS update required: The smart device OS version is not compatible and must be updated.

To establish a connection with an EXFO EX1 device:

1. Select a device from the list. A pop-up is displayed while trying to establish the connection with the selected EXFO EX1 device.

If the connection succeeds, **Connected** is displayed next to the connected EXFO EX1 device.

2. If the connection fails (not connected) ensure that the EXFO EX1 device is in-range, within 1 meter to 30 meters depending on the obstacle and interference, and select the device again.
3. If the **Incompatibility Detected** page is displayed, the firmware of the EXFO EX1 device is not compatible with the smart device application and must be updated:
 - 3a. If the message **No Network connection on 10/100/1000M Electrical** is displayed, make sure the EXFO EX1 device is connected to the Internet using the RJ45 port (refer to *Connecting the RJ45 and SFP Ports* on page 13).

OR
 - 3b. If the message **No Network connection on Wi-Fi** is displayed, make sure the EXFO EX1 device is connected to the Internet using a Wi-Fi connection (tap the setting button  and connect to a Wi-Fi access point).

OR
 - 3c. If the message **Server unreachable through 10/100/1000M Electrical / Wi-Fi** is displayed, contact EXFO technical support.
 - 3d. Tap the **DOWNLOAD AND INSTALL** button to download and install the new firmware on the EXFO EX1 device. The EXFO EX1 device battery charge level must be more than 30% to perform a system update. Once the installation is completed, the EXFO EX1 device is automatically rebooted and the connection is established with the smart device.

To disconnect from an EXFO EX1 device:

1. Select the **Connected** EXFO EX1 device.
2. Select **Yes** to confirm its disconnection.

Speedtest

Note: *The **Speedtest** by Ookla is only available when connected to an EXFO EX1 device.*

From the **Speedtest** page it is possible to start the test, see the test in-progress, results/verdicts, and access the test report. Refer to *Speedtest* on page 25 for more information.

Reports

Note: The **Reports** page is only available when connected to an EXFO EX1 device.

The **Reports** page lists the EXFO EX1 test reports and allows report file management as follows:

Icon/Label	Action	Description
	Sort	Tap to change the report sorting order. Reports are sorted by their file name either ascending or descending (default).
Speedtest <Report File Name> <Report Tag>	Open	Tap on a report file name to open the report file. <Report File Name> is the report file name. <Report Tag> is an optional report tag name.
	Select Report	Tap on either icons to select the report or combined report. When at least one report is selected, the report is in the selection mode allowing additional controls as described in the following table. The number of selected reports is displayed next to the back button.
	Select Combined Report	
	Cancel the selection	Indicates that the report is selected. Tap on this icon to cancel the selection.

EXFO EX1 Main Menu

Reports

The following controls are available/displayed when at least one report is selected:

Icon	Action	Description
	Back	Exits the report selection mode and returns to the Reports page.
	Rename a Report ^a	Tap to change the name of a report.
	Tag a Report ^a	Tap to tag a report. Select a predefined tag or User Defined to create your own tag.
	Combine Reports ^b	Combines reports together to create a new combined report. Reports are appended one after the other without altering the content of individual reports and ordered based on their generation date and time. It is possible to add additional individual reports (not combined reports) to an existing combined report.
	Delete	Deletes the selected report(s) from the EXFO EX1 device memory.
	Share	Shares the selected report(s) with relevant applications installed on the smart device.
	Select all	Selects all reports.

- a. Available when a single report is selected.
- b. Available when at least two reports are selected.

Reports are stored on the EXFO EX1 device memory which is limited to 500 reports. It will not be possible to start a Speedtest once this limit is reached, a message will be displayed.

About

Version and Copyrights

Displays the version of the EXFO EX1 application and copyrights (**EXFO** and **Speedtest by Ookla**).

Help

User Guide opens the EXFO EX1's user guide (PDF format) describing both the EXFO EX1 device and the EXFO EX1 application.

Technical Support

Displays technical support phone numbers, website and e-mail in order to contact EXFO. Refer to *Contacting the Technical Support Group* on page 52 for more information.


License Agreements

Displays respectively the **EXFO License Agreement**, **Ookla Terms & conditions**, and **GNU General Public Licenses** containing links to access the latest online license agreements and/or terms & conditions.

5 Speedtest

The Speedtest is a proprietary testing methodology developed by Ookla¹ and used by EXFO EX1 device to determine the quality of the Internet connection offered by a given Internet Service Provider (ISP). It also allows the user to determine if the Service Level Agreement (SLA) is properly met. The quality of the connection is evaluated by determining the round-trip delay and throughput speed in the download and upload directions between a client located at an access point and an Ookla server.

From the main menu select **Speedtest**.



1. Ookla is a third party provider. The Ookla Speedtest Powered technology involves Ookla owned and/or controlled servers that may or may not be within your network. Ookla retains the right to aggregate test results and to monetize aggregated results as they see fit.

Speedtest

Start/Stop

Note: The **Speedtest** page is selected by default whenever the EXFO EX1 application successfully connects to any EXFO EX1 device. The page displays the results of the last executed test when available.

Start/Stop

The Start/Stop button starts or stops the **Speedtest**.

Button	Description
	Starts the Speedtest .
	Stops the Speedtest .

Note: Every time the **Speedtest** is run, the following Ookla privacy policy agreement is displayed:

You, end user, understand and acknowledge by performing the test contained in the Speedtest Software Application, that Ookla, LLC, may collect your IP Address during the test and share it with selected third parties.

The **Don't remind me again** check box, when selected, forgoes displaying the Ookla privacy policy agreement next time the test is run. This setting can also be enabled/disabled from Ookla Privacy Notice on page 37.

Ookla Privacy Policy: <http://www.speedtest.net/privacy>

Client/Server Information

Displays the following client and server Information:

Icon	Information
	The name of the Internet Service Provider. The WAN client IP Address.
	The name of the host server. The IP address of the host server.

Expandable Status Bar

The status bar is an expandable area that is collapsed by default.

The collapsed view displays the following information:

Information	Description
Link	For RJ45: Indicates the auto-negotiated rate: 10M , 100M , or 1GE .
	For SFP: Indicates either GPON or the rate for 1 GE interface, laser status, and power level. The presence of the laser icon indicates that the laser is on; otherwise the laser is off (the icon is not displayed). The rate and power level (dBm) are displayed when a valid signal is received.
	For Wi-Fi: Indicates the Wi-Fi radio signal strength (icon), the frequency band in GHz, and the link speed in Mbit/s.
Current alarms/errors	For RJ45: Indicates if a Link Down alarm occurred during the last second.
	For SFP (1 GE): Indicates if a Link Down or LOS alarm occurred during the last second.
	For SFP (GPON): Indicates if a LOS or GPON Down alarm occurred during the last second. GPON Down is declared when the ONU is not in operation-state.
	For Wi-Fi: Indicates if a Wi-Fi Down (no connection) alarm occurred during the last second.

Speedtest

Expandable Status Bar

Information	Description
Global Pass/Fail verdict	Displays the global test pass/fail verdict icon, when enabled. Pass  indicates that all result values meet the configured threshold criteria. Fail  indicates that at least one result value does not meet the configured threshold criteria, an alarm is detected, or the test is aborted.

Once the test is completed, the status bar is automatically expanded. The expanded view displays the following additional information:

Information	Description
Started at	The date and time the test started.
Stopped at	The date and time the test ended.
Status is	The status of the test: Idle : The test is not running or results are not available. In-Progress : The test is running. Completed : The test is completed. Aborted - <reason>: The test has been interrupted and the reason is displayed: Link Down, LOS, GPON Down, Network Timeout, Unresolved IP Address, Server Unavailable, Ookla Server Unreachable, User Stopped, Report Count Exceeded, Wi-Fi Down.

To expand the status bar:

1. Tap on the status bar.
OR
2. Tap and swipe down the status bar.

To collapse the status bar:

1. Tap on the status bar, within the status bar area, or anywhere outside the expanded status bar area.
OR
2. Tap and swipe up the status bar area.

Subtests

Latency, **Download**, and **Upload** subtests are performed sequentially and report their results using live visual meters. While the test is running, the Speedtest page auto-scrolls to display the current running subtest but can be overruled by touching the screen. A progress indicator is displayed indicating the subtest that is currently running and live results are reported on the meter. At the end of each test, the visual meter indicates the final results and an individual verdict is displayed when enabled (refer to *Thresholds* on page 32). Once a first subtest is completed, the global verdict is calculated and reported when enabled (see *Expandable Status Bar* on page 27). Once all subtests are completed, the quick report button is available to see the test report.

Note: *Speedtest uses TCP and requires that the port 8080 is not blocked allowing TCP type transactions on the network.*

Latency

Measures the round-trip time between the client and the Ookla server.

Download¹

Measures the aggregated throughput speed from the Ookla server to the client.

Upload¹

Measures the aggregated throughput speed from the client to the Ookla server.

1. When performed over Wi-Fi, these tests are influenced by the Wi-Fi network meaning that on the fly the channel link speed may change to a lower or higher value depending on the surrounding environment which includes: Wi-Fi protocol lowering the link speed for backward compatibility, interference from other device types such as microwave oven, Bluetooth devices, the number of devices present in the vicinity dividing the bandwidth to the access point, and the load balancing between access points in business type environments. The Wi-Fi parameters are continuously updated to represent what is on-going in the Wi-Fi environment, except while the test is running.

Speedtest

Quick Report

Quick Report

Tap the quick report button  to view and share the current test report. Refer to *Reports* on page 21 to view and share a previously saved Speedtest report.

Settings

Tap the settings button  to configure the test, reports, and system parameters. Refer to *Speedtest Settings* on page 31 for more information.

6 **Speedtest Settings**

The **Settings** page allows the configuration of the test, reports, and system parameters.

From the Speedtest page, tap the settings button .

Test

Speedtest Servers

Determines how the Speedtest server will be selected.

- **Automatic** indicates that the server closest to the client is automatically selected following the Ookla proprietary method.
- **Manual** followed by the server name indicates that the server has been manually selected by the user.

To manually select a SpeedTest server:

1. Tap on the **Speedtest Servers** field.
2. For manual selection, select either a server from the list of the 25 closest servers or use the search to find the desired server based on its server name, country, or sponsor (Service Provider Name).

To restore automatic SpeedTest server selection:

1. Tap on the **Speedtest Servers** field.
2. Tap on **SELECT AUTOMATICALLY** to clear the selected server.

Speedtest Settings

Test

Thresholds

Allows enabling and setting the threshold values that will be used to declare the pass/fail verdict for each test. Thresholds are disabled by default. Threshold settings are saved independently for each interface type: RJ45 and Wi-Fi.

- **Latency Threshold** when enabled, allows entering the maximum threshold value in ms.
- **Download Threshold** when enabled, allows entering the minimum and maximum threshold values in Mbits/s.
- **Upload Threshold** when enabled, allows entering the minimum and maximum threshold values in Mbits/s.

Interface

Allows selecting the test interface and its parameters.

- **Type/Rate** allows the selection of the EXFO EX1 device test port to use for the Speedtest: **10/100/1000M Electrical** (default), **1GE Optical**, **GPON**, or **Wi-Fi**.

For RJ45 port (10/100/1000M Electrical):

- **Connector** indicates the port connector type which is **RJ45**.
- **Auto-Negotiation** indicates the state of auto-negotiation which is enabled.
- **Speed** allows to force the Auto-Negotiated speed to 1GE, 100M, or 10M to facilitate negotiation in certain environment. Default is auto detection (**Auto**).

For SFP port (1GE Optical and GPON):

- **Transceiver**, available with GPON, allows selecting the type of transceiver:
 - **EXFO Qualified** devices provide additional GPON statistics and support Speedtest provided the device is compatible with the customer network.
 - **Other** devices do not report GPON statistics but maybe able to run Speedtest.
- **Connector** indicates the port connector type which is **SFP**.
- **Laser** when enabled (default) activates the laser on the SFP/GPON transceiver.
- **Laser Off at Start-Up** when enabled (disabled by default) automatically turns off the laser when starting the EXFO EX1 device.
- **Auto-Negotiation** when enabled (default) advertises to the remote port which parameters to use. Only available for 1GE Optical.
- **TX Power** indicates the transmit power level in dBm.
- **RX Power (Min/Current/Max)** indicates respectively the receive power level minimum, current, and maximum level in dBm.
- **RX Power Range** indicates the receive power range level in dBm supported by the SFP/GPON.
- **SFP Information**, available with SFP transceiver, gives detailed information related to the transceiver module.
- **GPON Information**, available with GPON transceiver, displays the following information: **ONU Serial Number**, **ONU Password**¹, **Active SW Version**¹, **Inactive SW Version**¹, **Equipment ID**¹, **ONU State**, **ONU ID**, **PON ID**, **OLT Vendor ID**, **OLT Version**, **Transmit Optical Level (TOL)**, **ODN Class**, and **ODN Loss**.

1. These ONU parameters are configurable for **EXFO Qualified** transceivers.

Speedtest Settings

Test

For Wi-Fi:

When selecting Wi-Fi as the interface type/rate, the Wi-Fi connection status is reported as follows:

Status Message	Description
Connecting...	Trying to connect to an access point.
Connection Error	Unable to connect to the access point.
Connection Error Invalid Credential	Unable to connect to the access point due to invalid credential.
Connected	Connection is established with an access point.
Not Connected	No connection to an access point (SSID) has been established yet.
Not in Range	A known access point that is not available.

- **Not Connected** indicates that no connection to an access point has been established yet.
- **Wi-Fi** followed by an access point indicates that the EXFO EX1 device is connected to an access point.
 -  The setting button allows either setting, changing, or disconnecting to/from an access point (see *Wi-Fi* on page 39).
- **Channel Map** (see *Wi-Fi* on page 39)

To connect to an access point (when Not Connected is displayed):

1. Tap the setting button.
2. Enter the credentials to connect to this access point.

To disconnect from an access point:

1. Tap the setting button.
2. Tap the **Connected** access point.
3. Tap **FORGET**.

To change the access point:

1. Tap the setting button.
2. Tap the new access point.
3. Enter the credentials to connect to this access point.

To display the parameters of an access point:

1. Tap the setting button.
2. Tap the connected access point (SSID) to display its parameters (see *Wi-Fi* on page 39).

Speedtest Settings

Test

Network

- **MAC Address** is the unique Media Access Control Address given to the EXFO EX1 device Ethernet or Wi-Fi port. Each port has its own MAC address that is editable for the RJ45 and SFP connectors. To change the MAC address, tap on the MAC address, enter the new MAC address, and tap **OK**. The new MAC is displayed followed by **(custom)**. To retrieve the default MAC address, tap on the MAC address and tap **RESTORE TO DEFAULT**.
- **VLAN**: The **VLAN** when enabled (disabled by default), enables one level of VLAN encapsulation: C-VLAN (type 8100).
- **VLAN ID** choices are **0** through **4095** (default is **2**).

Special VID values (IEEE Std 802.1Q-1998):

ID	Description
0	The null VLAN ID. Indicates that the tag header contains only user priority information; no VLAN identifier is present in the frame. This VID value must not be configured as a PVID, configured in any Filtering Database entry, or used in any Management operation.
1	The default PVID value used for classifying frames on ingress through a Bridge Port. The PVID value can be changed on a per-Port basis.
4095	Reserved for implementation use. This VID value shall not be configured as a PVID, configured in any Filtering Database entry, used in any Management operation, or transmitted in a tag header.

- **VLAN Priority** choices are **0** (default) to **7**:

0	000 - Low Priority	4	100 - High Priority
1	001 - Low Priority	5	101 - High Priority
2	010 - Low Priority	6	110 - High Priority
3	011 - Low Priority	7	111 - High Priority

- **VLAN Type** choices are **8100** (default) for C-VLAN and **88A8** for S-VLAN.

➤ **DHCP/Static/PPPoE**

- **DHCP** (default) when selected dynamically obtains an IP address from a DHCP (Dynamic Host Configuration Protocol) server. **DHCP** is enabled and not configurable when using Wi-Fi. The source **IP Address, Subnet Mask, Gateway, DNS1**, and **DNS2** parameters are displayed.
- **Static** when selected allows setting the source parameters: **IP Address, Subnet Mask, Gateway, DNS 1**, and **DNS 2**.
- **PPPoE** when selected allows using a Point-to-Point Protocol over Ethernet connection.

Authentication allows configuring the **User Name** and **Password** and displays the connection status: **Not Connected, Connecting, Connected**.

Connection Mode:

Always On automatically connects and maintains the connection to the PPPoE server.

On-Demand (default) automatically connect/disconnect to/from the PPPoE server when data transmission is initiated/terminated on the PPPoE client.

The source **IP Address, DNS1**, and **DNS2** parameters are displayed.

Ookla Privacy Notice

Defines if the following Ookla Privacy Notice is displayed (enabled - default) or hidden (disabled) every time the Speedtest is started.

You, end user, understand and acknowledge by performing the test contained in the Speedtest Software Application, that Ookla, LLC, may collect your IP Address during the test and share it with selected third parties.

Speedtest Settings

Reports

Reports

Allows configuration of report identification information and file format.

Job Information

Note: *Job Information may not be available on all EXFO EX1 device versions.*

These fields are not mandatory and are used to identify the report. Enter the following job information if required: **Job ID**, **Customer Name**, **Contractor Name**, **Operator Name**, **Circuit ID**, and **Comment**.

Up to 32 characters are allowed for each field with the exception of **Comment** which allows 160 characters.

Share Format


Allows the selection of the report file format to be generated, either **PDF** (default) and/or **CSV**.

System

Allows configuration of the EXFO EX1 device settings.

Wi-Fi

- **MAC Address** is the default and unique Media Access Control (MAC) address given to the Wi-Fi of the EXFO EX1 device.
- **Channel Map** provides a dynamic view of all active 2.4 GHz or 5 GHz access points.
 - **Excellent, Good, Fair, Weak** selection allows displaying access points based on their signal strength.
 - **2.4 GHz** and **5 GHz** selection allows displaying access points based on the selected frequency band.
 - **All/36-64/100-144/149-165**, available with 5 GHz, allows selecting the channel range to be displayed.
 - The graph displays each Wi-Fi channel (X axis) with their signal strength (Y axis) and are color coded allowing their identification with the list of access points that appear below the graph.



Speedtest Settings

System

- The list of access points are color coded allowing their identification on the graph. Each access point (SSID) is listed with its SSID, BSSID, vendor name, channel number, frequency (in parenthesis), and signal strength. If the connected Wi-Fi access point is part of the list, it appears as the first access point in the list with the icon  to its left.

Tap on an access point to highlight it on the graph. Tap again on the access point to un-select it. It is possible to highlight more access points by tapping on each access point.

- **Wi-Fi Access Points** allow the EXFO EX1 device to connect to a Wi-Fi access point¹ for testing, or downloading and installing new firmware update (see *Device Information* on page 43).

For a secured access point enter the password and tap **CONNECT**.

- **Show Password** check box when selected displays the password.
- **Show Advanced** check box when selected displays the access point DHCP and security information.

Tapping on the **Connected** Wi-Fi access point displays the following information:

Wi-Fi Details

- **BSSID:** Basic Set Identifier
- **Vendor:** Manufacturer name
- **Frequency Band:** 2.5 GHz or 5 GHz
- **Channel:** Actual number associated to a channel: **1** to **14** for 2.5 GHz; **1** to **200** for 5 GHz.

1. Connection is only possible on access points having their security mode set to either **Unsecured** or **WPA2 - Personal**.

- **Signal Strength:** The received signal strength of the Beacon frame in dBm.

Signal Strength	Signal strength value in	
	Percentage	dBm
Excellent	100 %	> -50 dBm
Good	80 % to 100 %	-50 dBm to -60 dBm
Fair	60 % to 80 %	< -60 dBm to -70 dBm
Weak	40 % to 60 %	< -70 dBm to -80 dBm

- **Link Speed:** Link speed value of the connected Wi-Fi network in Mbit/s.
- **Security:** The Wi-Fi interface security mode.

Security Mode	Description
Unsecured	Security is disabled
WPA2 - Personal	Wi-Fi Protected Access Personal Version 2

Network: The connected Wi-Fi network information: **IP Address, Subnet Mask, Gateway, DNS 1, DNS 2.**

CANCEL and **FORGET** allows respectively to close the pop-up or disconnect from this Wi-Fi access point.

Diagnostics

Report Diagnostic Data

Enable this feature to help improve your EX1 experience by automatically sending diagnostic data (Settings, activity logs, fault logs, ...) to EXFO. This information will not be used to identify you and will help improve the performance and stability of the product.

See Section 4.8 and Section 6 of the Software License Agreement (refer to *License Agreements* on page 23) for additional details.

Turning off this feature does not affect your device's ability to operate normally to share reports or request firmware updates.

Date/Time

Automatic Date/Time is enabled (not configurable) and set to **Automatic** meaning that the EXFO EX1 device uses the smart device date and time.

Battery

- **Charge remaining** indicates the EXFO EX1 device battery status (icon) and the percentage of the remaining battery charge level as follows:

Icon	Level of charge
	Charge remaining when above 5%. A low battery message is displayed when the battery goes below 25% indicating to charge the EXFO EX1 device to extend operation.
	Charge remaining when below 5%. A very low battery message is displayed when the battery goes below 5% indicating that the EXFO EX1 device will shortly shut down and to charge the EXFO EX1 device to extend operation.
	Plugged in and charging.
	Plugged in but not charging, the power source is not sufficient to charge the EXFO EX1 device.

➤ **Power Saving**

- **Auto-Shutdown** when enabled (default), allows the EXFO EX1 device to shut down once the period of inactivity is reached. The EXFO EX1 device shuts down when there is no activity on the device (no HTTP communication, test not running, no firmware update, EXFO EX1 application in closed or in background, etc.) for the defined period. When the EXFO EX1 device is charging using the provided USB power adapter, the Auto-Shutdown feature is disabled.
- **Period**, available when **Auto-Shutdown** is enabled, allows setting the inactivity time before turning off the EXFO EX1 device:
1:00 min to 5:00 min (3:00 min by default) in 30-second steps.

Device Information

Displays EXFO EX1 device information and allows firmware update and device name edition.

➤ **Software**

- **Product Version** indicates the installed EXFO EX1 device firmware version.
- **Network Repository Server** indicates the server address for software update. This field is editable for technical support purposes only. This field is editable for demo, beta, or technical support purposes. Press the **Restore to Default Server** button to retrieve the default server address.

Speedtest Settings

System

- **System Update** checks for new firmware update and allows its installation.

If a new firmware update is available, tap the **DOWNLOAD AND INSTALL** button to download and install the new firmware on the EXFO EX1 device. A RJ45 or Wi-Fi (see *Wi-Fi* on page 39) connection is required on the EXFO EX1 device. The EXFO EX1 device battery charge level must be more than 30% to perform a system update.

Once the installation is completed, the EXFO EX1 device is automatically rebooted and the connection is automatically re-established by the smart device.

- **Device**

Displays the following EXFO EX1 device information: **Device Name**, **Model Number**, **Serial Number**, **Assembly Hardware Revision**, and **Manufacturing Date**. The **Device Name** is editable.

7 **Maintenance**

To help ensure long, trouble-free operation:

- Always inspect fiber-optic connectors before using them and clean them if necessary.
- Keep the unit free of dust.
- Clean the unit casing and front panel with a cloth slightly dampened with water.
- Store unit at room temperature in a clean and dry area. Keep the unit out of direct sunlight.
- Avoid high humidity or significant temperature fluctuations.
- Avoid unnecessary shocks and vibrations.
- If any liquids are spilled on or into the unit, turn off the power immediately, disconnect from any external power source, remove the battery and let the unit dry completely.



WARNING

The use of controls, adjustments and procedures, namely for operation and maintenance, other than those specified herein may result in hazardous radiation exposure or impair the protection provided by this unit.

Recalibrating the Unit

The EXFO EX1 device does not require any calibration.

Recharging the Battery

The battery in the EXFO EX1 device is a rechargeable Li-ion smart battery. The EXFO EX1 device USB-C adapter connector is used to recharge its battery. The EXFO EX1 device has a LED indicating the battery charge status (refer to *Battery LED* on page 5). The EXFO EX1 device battery charge status is also available on the smart device application (refer to *Device Information* on page 17 and *Battery* on page 42).



CAUTION

Only charge the EXFO EX1 device battery with the USB cable and USB power adapter provided by EXFO.

You can purchase a new battery from EXFO.



IMPORTANT

The battery of the EX1 device is not fully charged at the factory. Charge the battery before using the EX1 device for the first time or when it has been unused for extended periods. The battery is fully charged when the battery green LED stops flashing. The charge cycle starts and stops automatically.

The time required to charge the battery depends on various factors such as the ambient temperature.

To ensure that the battery functions or charges properly, keep it within operation and storage temperature range.

It is possible to use the provided USB cable alone connected to a USB port of a computer to recharge the battery only when the EXFO EX1 device is turned off. The power supplied from a computer USB port is not sufficient to charge the EXFO EX1 device when it is turned on.

Replacing the Battery

The EXFO EX1 device is powered by a rechargeable Li-ion smart battery.



WARNING

Only replace the rechargeable Li-ion smart battery of the EXFO EX1 device with a battery of the same type and model. The use of other batteries may damage your unit and compromise your safety.

Battery replacement should only be done by a qualified technician with the appropriate tools on an electronic bench or similar environment.

Do not throw the battery into fire or water and do not short-circuit the battery electrical contacts. Do not disassemble.



CAUTION

To avoid irremediable damage to the battery, always remove the battery compartment door carefully, ensuring that the battery does not fall.

Maintenance

Replacing the Battery

To replace the battery:

1. Turn off the EXFO EX1 device.
2. Unplug any power cable.
3. Using a screwdriver, remove the screw that is located on the back of the EXFO EX1 device.



4. Remove the battery compartment door.



CAUTION

Gently pull on the battery to avoid damaging the wires.

5. Remove the battery and disconnect the wires.
6. Replace the battery and reconnect the wires.
7. Close the battery compartment door.
8. Using a screwdriver, put the screw that was removed at step 3 back in place.

Cleaning LC Connectors

Under normal circumstances the cleaning of the LC connector is not required. However if the connector shows signs of debris or contamination, cleaning may be required.

To clean an LC connector

- 1.** Use a clean dry air (CDA) or a air gun to blow out the dust or contamination.
- 2.** Re-inspect the connector.
- 3.** If the connector is still not clean, use a commercial cleaner recommended by the transceiver manufacturer.

Note: *Refer to the transceiver manufacturer for more detailed cleaning recommendations and instructions.*

Recycling and Disposal



This symbol on the product means that you should recycle or dispose of your product (including electric and electronic accessories) properly, in accordance with local regulations. Do not dispose of it in ordinary garbage receptacles.

For complete recycling/disposal information, visit the EXFO Web site at www.exfo.com/recycle.

8 Troubleshooting

Solving Common Problems

Before calling EXFO's technical support, please read the following common problems that can occur and their respective solution.

Problem	Possible Cause	Solution
Unable to establish the connection between the smart device and an EXFO EX1 device.	Too much distance between the smart device and the EXFO EX1 device.	Reduce the distance between the two devices.
	The Smart Device hardware may not be supported by the application. Need to contact EXFO for list of supported devices.	Make sure that both devices use compatible firmware and application versions.
The EXFO EX1 device is not appearing in the list of Available Devices from the Connection menu.	Too much distance between the smart device and the EX1 device.	Reduce the distance between the two devices.
	EX1 device is already connected to another smart device.	Disconnect the EXFO EX1 device from the other smart device.
	EXFO EX1 device is powered off.	Turn the EXFO EX1 device on.
	EXFO EX1 device is booting.	Wait until the EXFO EX1 device is completely booted (refer to <i>On/Off Switch and LED</i> on page 4).
The EXFO EX1 device automatically turns off.	Insufficient battery power.	Recharge the battery using the supplied USB power adapter.
	The EX1 device automatically shuts down after 3 minutes (by default) of inactivity when the EX1 device is not charging using the supplied USB power adapter.	Turn the EXFO EX1 device on and if required, increase the inactivity time before turning the unit off. Refer to Power Saving on page 43 for more information.
	High temperature environment.	Make sure to use the EXFO EX1 device within its operating temperature range. Refer to <i>Equipment Rating</i> on page 57.
Unable to combine reports.	Reports were generated with a version prior to version 1.3.	Ensure reports were created with version 1.3 or above.

Troubleshooting

Contacting the Technical Support Group

Contacting the Technical Support Group

To obtain after-sales service or technical support for this product, contact EXFO at one of the following numbers. The Technical Support Group is available to take your calls from Monday to Friday, 8:00 a.m. to 7:00 p.m. (Eastern Time in North America).

Technical Support Group

400 Godin Avenue
Quebec (Quebec) G1M 2K2
CANADA

1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
Fax: 1 418 683-9224
support@exfo.com

For detailed information about technical support, and for a list of other worldwide locations, visit the EXFO Web site at www.exfo.com.

If you have comments or suggestions about this user documentation, you can send them to customer.feedback.manual@exfo.com.

To accelerate the process, please have information such as the name and the serial number (see the product identification label), as well as a description of your problem, close at hand.

Transportation

Maintain a temperature range within specifications when transporting the unit. Transportation damage can occur from improper handling. The following steps are recommended to minimize the possibility of damage:

- Pack the unit in its original packing material when shipping.
- Avoid high humidity or large temperature fluctuations.
- Keep the unit out of direct sunlight.
- Avoid unnecessary shocks and vibrations.

9 **Warranty**

General Information

EXFO Inc. (EXFO) warrants this equipment against defects in material and workmanship for a period of one year from the date of original shipment. EXFO also warrants that this equipment will meet applicable specifications under normal use.

During the warranty period, EXFO will, at its discretion, repair, replace, or issue credit for any defective product, as well as verify and adjust the product free of charge should the equipment need to be repaired or if the original calibration is erroneous. If the equipment is sent back for verification of calibration during the warranty period and found to meet all published specifications, EXFO will charge standard calibration fees.



IMPORTANT

The warranty can become null and void if:

- **unit has been tampered with, repaired, or worked upon by unauthorized individuals or non-EXFO personnel.**
- **warranty sticker has been removed.**
- **case screws, other than those specified in this guide, have been removed.**
- **case has been opened, other than as explained in this guide.**
- **unit serial number has been altered, erased, or removed.**
- **unit has been misused, neglected, or damaged by accident.**

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL EXFO BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Warranty

Liability

Liability

EXFO shall not be liable for damages resulting from the use of the product, nor shall be responsible for any failure in the performance of other items to which the product is connected or the operation of any system of which the product may be a part.

EXFO shall not be liable for damages resulting from improper usage or unauthorized modification of the product, its accompanying accessories and software.

Exclusions

EXFO reserves the right to make changes in the design or construction of any of its products at any time without incurring obligation to make any changes whatsoever on units purchased. Accessories, including but not limited to fuses, pilot lamps, batteries and universal interfaces (EUI) used with EXFO products are not covered by this warranty.

This warranty excludes failure resulting from: improper use or installation, normal wear and tear, accident, abuse, neglect, fire, water, lightning or other acts of nature, causes external to the product or other factors beyond the control of EXFO.



IMPORTANT

In the case of products equipped with optical connectors, EXFO will charge a fee for replacing connectors that were damaged due to misuse or bad cleaning.

Certification

EXFO certifies that this equipment met its published specifications at the time of shipment from the factory.

Service and Repairs

EXFO commits to providing product service and repair for five years following the date of purchase.

To send any equipment for service or repair:

- 1.** Call one of EXFO's authorized service centers (see *EXFO Service Centers Worldwide* on page 56). Support personnel will determine if the equipment requires service, repair, or calibration.
- 2.** If equipment must be returned to EXFO or an authorized service center, support personnel will issue a Return Merchandise Authorization (RMA) number and provide an address for return.
- 3.** If possible, back up your data before sending the unit for repair.
- 4.** Pack the equipment in its original shipping material. Be sure to include a statement or report fully detailing the defect and the conditions under which it was observed.
- 5.** Return the equipment, prepaid, to the address given to you by support personnel. Be sure to write the RMA number on the shipping slip. *EXFO will refuse and return any package that does not bear an RMA number.*

Note: *A test setup fee will apply to any returned unit that, after test, is found to meet the applicable specifications.*

After repair, the equipment will be returned with a repair report. If the equipment is not under warranty, you will be invoiced for the cost appearing on this report. EXFO will pay return-to-customer shipping costs for equipment under warranty. Shipping insurance is at your expense.

Routine recalibration is not included in any of the warranty plans. Since calibrations/verifications are not covered by the basic or extended warranties, you may elect to purchase FlexCare Calibration/Verification Packages for a definite period of time. Contact an authorized service center (see *EXFO Service Centers Worldwide* on page 56).

Warranty

EXFO Service Centers Worldwide

EXFO Service Centers Worldwide

If your product requires servicing, contact your nearest authorized service center.

EXFO Headquarters Service Center

400 Godin Avenue
Quebec (Quebec) G1M 2K2
CANADA

1 866 683-0155 (USA and Canada)
Tel.: 1 418 683-5498
Fax: 1 418 683-9224
support@exfo.com

EXFO Europe Service Center

Winchester House, School Lane
Chandlers Ford, Hampshire S053 4DG
ENGLAND

Tel.: +44 2380 246800
Fax: +44 2380 246801
support.europe@exfo.com

EXFO Telecom Equipment (Shenzhen) Ltd.

3rd Floor, Building C,
FuNing Hi-Tech Industrial Park, No. 71-3,
Xintian Avenue,
Fuhai, Bao'An District,
Shenzhen, China, 518103

Tel: +86 (755) 2955 3100
Fax: +86 (755) 2955 3101
support.asia@exfo.com

To view EXFO's network of partner-operated Certified Service Centers nearest you, please consult EXFO's corporate website for the complete list of service partners:

<http://www.exfo.com/support/services/instrument-services/exfo-service-centers>.

A Specifications



IMPORTANT

The following technical specifications can change without notice. The information presented in this section is provided as a reference only. To obtain this product's most recent technical specifications, visit the EXFO Web site at www.exfo.com.

General Specifications

Equipment Rating

Specification	
Size (H x W x D)	125 x 75 x 45 mm (5 x 3 x 1 3/4 in)
Weight (without transceiver)	0.45 kg (1 lb)
Temperature - Operating	0 °C to 40 °C (32 °F to 104 °F)
Temperature - Charging battery	0 °C to 35 °C (32 °F to 95 °F)
Temperature - Storing	Without battery: -40 °C to 70 °C (-40 °F to 158 °F) With battery (less than 1 month): -10 °C to 40 °C (14 °F to 104 °F) With battery (1 to 12 months): 0 °C to 30 °C (32 °F to 86 °F)
Relative humidity	0 % to 93 %, non-condensing
Maximum operation altitude	2000 m (6560 ft)
Pollution degree	3
Measurement category	Not rated for measurement categories II, III, or IV
Input Power	 5 V; 2 A
USB Adapter Power	 100 — 240 V; 50/60 Hz; 1 A  5 V; 2.4 A

B *Glossary*

Acronym List

?	Help
---	------

A

AC	Alternating Current
----	---------------------

B

BLE	Bluetooth Low Energy
BSSID	Basic Service Set Identifier

C

CAGE	Commerce And Government Entities
CDA	Clean Dry Air
CSV	Comma Separated Value

D

D	Depth
dBm	Decibel milliwatts
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name System

Glossary

Acronym List

E

EFTA	European Free Trade Association
EIRP	Equivalent Isotropically Radiated Power
EU	European Union
EUI	EXFO Universal Interfaces

F

FCC	Federal Communications Commission
FPGA	Field-Programmable Gate Array

G

Gbit/s	Gigabit per second
GHz	Giga Hertz
GPON	Gigabit Passive Optical Network

H

H	Height
HTTP	Hypertext Transfer Protocol
Hz	Hertz

I

ICED	Interference-Causing Equipment Standard
ID	Identification
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical & Electronics Engineers

ISED	Innovation, Science and Economic Development
ISP	Internet Service Provider

L

LAN	Local Area Network
LED	Light-Emitting Diode

M

MAC	Media Access Control
Mbit/s	Megabit per second
MHz	Mega Hertz
ms	milliseconds
mW	milli Watt

N

NATO	North Atlantic Treaty Organization
------	------------------------------------

P

PDF	Portable Document Format
PPPoE	Point-to-Point Protocol over Ethernet

R

RF	Radio Frequency
RMA	Return Merchandise Authorization
RSS	Radio Standards Specifications

Glossary

Acronym List

S

SFP	Small Form Factor Pluggable
SI	International System
SLA	Service Level Agreement
SSID	Service Set Identifier

T

TCP	Transmission Control Protocol
-----	-------------------------------

U

USA	United States of America
USB	Universal Serial Bus

V

VLAN	Virtual Local Area Network
------	----------------------------

W

W	Width
Wi-Fi	Wireless Fidelity

Ethernet Interface and Signal

Ethernet Interface	Ethernet Signal
10/100/1000 Mbit/s Electrical	10Base-T
	100Base-TX
	1000Base-T
100 Mbit/s Optical ^a	100Base-FX
	100Base-LX10
	100Base-BX10
1000 Mbit/s Optical	1000Base-SX
	1000Base-LX
	1000Base-ZX
	1000Base-BX10

- a. Future use.

Index

A	
About	23
Acronym	59
after-sales service	52
Android	15
App update required	18
Apple iOS	15
Apple Store	15
Assembly Hardware Revision	44
Authentication	37
Automatic	31
Auto-Negotiation	32, 33
Auto-Shutdown	43
Available Devices	18
B	
Battery	5, 17, 42, 46, 47
Bluetooth	15
Bluetooth®	
frequency band data	viii
BSSID	40
C	
caution	
of personal hazard	8
of product hazard	8
Channel	40
Charge remaining	42
Circuit ID	38
cleaning	
front panel	45
Cleaning Optical Connectors	49
Client/Server Information	27
Comment	38
Connection	18
Connection Mode	37
Connector	32, 33
Contractor Name	38
conventions, safety	8
Customer Name	38
customer service	55
D	
Date and time	17
Date/Time	42
Device	44
Device Information	43
Device Name	17, 44
DHCP	37
Diagnostics	42
DNS 1	41
DNS 2	41
Download	29
DOWNLOAD AND INSTALL	19
Download Threshold	32
E	
Equipment rating	57
equipment returns	55
EX1 update required	18
F	
Frequency Band	40
frequency, Bluetooth® and Wi-Fi	viii
front panel, cleaning	45
G	
Gateway	41
Google	15
GPON	14
GPON Information	33

Index

	H		
Help		23	
	I		
identification label		52	
Interface		32	
IP Address		37, 41	
	J		
Job ID		38	
Job Information.....		38	
	L		
label, identification		52	
Laser Off at Start-Up		33	
Latency.....		29	
Latency Threshold		32	
License Agreements		23	
Link Speed.....		41	
	M		
MAC Address.....		36, 39	
maintenance			
front panel		45	
general information.....		45	
Manual.....		31	
Manufacturing Date.....		44	
Model Number		44	
	N		
Network Repository Server		43	
No Network connection on 10/100/1000M Elec- trical.....		19	
No Network connection on Wi-Fi		19	
	O		
On/Off switch.....		4	
Ookla		25	
Ookla Privacy Notice.....		37	
Operator Name.....		38	
OS update required		18	
	P		
Period.....		43	
Play Store		15	
Power Saving.....		43	
PPPoE		37	
product			
identification label		52	
specifications		7, 57	
Product Version		43	
	Q		
Quick Report.....		30	
	R		
Recharging the battery		46	
regulatory information		v	
Replacing the battery		47	
Report		30	
Reports.....		21, 38	
Reset button.....		6	
return merchandise authorization (RMA)		55	
RJ45.....		7	
RJ45 Port		13	
RX Power (Min/Current/Max)		33	
RX Power Range		33	
	S		
safety			
caution		8	
conventions		8	
warning		8	
Security		41	
Serial Number.....		44	
service and repairs.....		55	
service centers		56	
Settings		30	

SFP 14

SFP Information..... 33

SFP Port..... 14

Share Format..... 38

shipping to EXFO 55

Signal Strength 41

Software 43

Special VID values 36

specifications, product 7, 57

Speed 32, 33

Speedtest 20, 25

Speedtest Servers 31

Start 26

Started at 28

Static 37

Status bar 27

Status is..... 28

Stop 26

Stopped at 28

storage requirements 45

Subnet Mask 41

Subtests 29

symbols, safety..... 8

System 39

System Update 44

T

technical specifications..... 7, 57

Technical Support..... 23

technical support 52

temperature for storage 45

Test 31

Thresholds..... 32

Transceiver 33

transportation requirements 45, 52

TX Power 33

Type/Rate 32

U

Upload 29

Upload Threshold..... 32

USB-C 3

User Guide..... 23

V

Vendor 40

Version and Copyrights 23

VID 36

VLAN 36

VLAN ID 36

VLAN Priority 36

VLAN Type 36

W

warranty

- certification..... 54
- exclusions 54
- general..... 53
- liability 54
- null and void 53

Wi-Fi 34

- frequency band data..... viii

Wi-Fi Access Points 40

CHINESE REGULATION ON RESTRICTION OF HAZARDOUS SUBSTANCES (RoHS)
中国关于有害物质限制的规定

NAMES AND CONTENTS OF THE TOXIC OR HAZARDOUS SUBSTANCES OR ELEMENTS
CONTAINED IN THIS EXFO PRODUCT
包含在本 EXFO 产品中的有毒有害物质或元素的名称及含量

Part Name 部件名称	Lead 铅 (Pb)	Mercury 汞 (Hg)	Cadmium 镉 (Cd)	Hexavalent Chromium 六价铬 (Cr(VI))	Polybrominated biphenyls 多溴联苯 (PBB)	Polybrominated diphenyl ethers 多溴二苯醚 (PBDE)
Enclosure 外壳	O	O	O	O	O	O
Electronic and electrical sub-assembly 电子和电气组件	X	O	X	O	X	X
Optical sub-assembly ^a 光学组件 ^a	X	O	O	O	O	O
Mechanical sub-assembly ^a 机械组件 ^a	O	O	O	O	O	O

Note:

注:

This table is prepared in accordance with the provisions of SJ/T 11364.

本表依据 SJ/T 11364 的规定编制。

O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。

X: indicates that said hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572. Due to the limitations in current technologies, parts with the “X” mark cannot eliminate hazardous substances.

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 标准规定的限量要求。

标记“X”的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。

a. If applicable.

如果适用。

MARKING REQUIREMENTS
标注要求

Product 产品	Environmental protection use period (years) 环境保护使用期限 (年)	Logo 标志
This EXFO product 本 EXFO 产品	10	
Battery ^a 电池	5	

a. If applicable.
如果适用。

P/N: 1079421

www.EXFO.com · info@EXFO.com

CORPORATE HEADQUARTERS 400 Godin Avenue

Quebec (Quebec) G1M 2K2 CANADA
Tel.: 1 418 683-0211 · Fax: 1 418 683-2170

TOLL-FREE (USA and Canada)

1 800 663-3936

© 2020 EXFO Inc. All rights reserved.
Printed in Canada (2020-04)

