Timbakote

APPLIED TO
INNOVA WOODGRAIN

Natural Timber Finishes

APPLICATION GUIDE

- First coat: Apply one coat of Base Coat.
- Second and third coats: Apply two coats of your chosen colour using an applicator pad. Avoid using a brush, as overlapping strokes can create uneven colour depth. Airless spray application also works well for a smooth, even finish.
- For best results: Avoid applying in hot conditions, as the coating may dry too quickly to achieve a consistent finish. Maintain a wet edge to minimise visible overlaps.
- For more information see; Timbakote Overview



DARK OAK



IRON BARK



REDWOOD



LIGHT CEDAR



CHARCOAL



NUTMEG

CLICK TO VIEW FULL RANGE OF COLOUR OPTIONS